

Wires-X for FT-70D

Push "F" then "AMS"

then after the blinking stops you see either
"LC", or "CN", or "CO"

"LC" means ~~that~~ there is no Room connected

"CN" means a room is connected via the Internet

"CO" shows the most recent node or room that you have been on.

Turn your KNOB (ontop of radio) until you see

EN _ _ _ _ _

Enter the room number you want

Push "AMS" or The PTT to save

then you will see it connect to the room

Once there you can listen & talk

Push & hold "Band" key to disconnect from your Room

Push & hold "Mode" key to exit Wires-X mode.